



Solid fuel kit fitting guide

Optional accessory instructions

EN 13240:2011 +A2:2004

BK 735 Rev 02

ISSUE DATE : 14/01/2020




Solid fuel kit fitting guide



1. Contents Of Kit :

Please Note—Shape Of Components May Vary Depending Upon Model

1 no.
Solid Fuel Liner
(Ceramic—Left
hand)



1 no.
Solid Fuel Liner
(Ceramic—Right
hand)



1 no. Solid Fuel Retainer

2. Warnings :



IMPORTANT—Please ensure the appliance is cold and unlit before commencing fitting this accessory kit.

Please refer to the main instruction booklet, relevant to your stove, for guidance and operation of the appliance, when using solid fuel.

Arada Ltd will not be responsible for any consequential or incidental loss or injury however caused.

Please note, this accessory kit can be fitted once the appliance (stove) has been installed and connected to the flue system, within the property.

Note, no technical knowledge is require to fit this kit.

Solid fuel kit fitting guide

3. Fitting Procedure

Before starting this process, please ensure that the firebox is cold and all the ash bed has been removed and cleaned.

Step 1 : Open the fire door & carefully remove the original fuel retainer. Keep this safe for future use.

Step 2 : Take the operating tool and insert the fork end into the location slots within the rear of the grate surround. Proceed to lift the grate surround up and with draw it from the firebox. See figure 1.





Figure 1. Removing The Grate Surround


Step 3 : Remove both of the base liner either side of the revolving grate. Again keep these safe for future use in the even that the appliance is returned back to a wood only device.

Step 4 : Take one of the ceramic solid fuel base liners and place into the firebox along side the revolving grate. Ensure the largest side of this liner is against the side liner. See figure 2. Repeat the process for the remaining side.

Solid fuel kit fitting guide



Step 5 : Finally place the solid fuel retainer into position, engaging the two tabs within the front brace of the appliance. See figure 3. The appliance is now set for solid fuel use.





Rear heat shield kit fitting guide

Optional accessory instructions

EN13240:2011 +A2:2004

BK736 Rev 02


ISSUE DATE: 14/01/2020



Rear heat shield kit fitting guide

1. Contents Of Kit :

2 no.
Heat Shield
Mount Bracket
(Stainless Steel—
Unpainted)



1 no. Heat Shield (Stainless Steel—Unpainted)

2. Warnings



IMPORTANT—Please ensure the appliance is cold and unlit before commencing fitting this accessory kit.

Please refer to the main instruction booklet, relevant to your stove, for guidance on the installation and operation of the appliance.

Arada Ltd will not be responsible for any consequential or incidental loss or injury however caused.

Please note, this accessory kit can only be fitted **prior** to the appliance (stove) being installed and connected to the flue system, within the property.

When handling the components of the kit, it is recommended to wear suitable gloves to prevent hand injuries.

Rear heat shield kit fitting guide

3. Fitting Procedure

Before starting this process, please ensure that the stove is cold and unlit

Step 1 : Working on the rear of the appliance, remove the 4x screw, indicated in figure 1.




Figure 1. Fixing Locations

Step 2 : Take one of the mounting brackets and fix in place using 2no. Of the screws removed in step 1. See figure 2.

Please note the orientation of the bracket




Figure 2. Mounting Brackets

Rear heat shield kit fitting guide

Step 3 : Repeat step 2 for the remaining mounting bracket.

Step 4 : Take the heat shield and position the mounting slots over the corresponding lugs on each side mounting bracket. Gently engage the lugs and push down, to locate the heat shield onto the mounting brackets as shown in figure 3.

Step 5 : With the heat shield fitted, please observe the revised distance to combustible materials, as stated in the instruction manual (BK 730).

Flue Pressure Test Point Location.
This can be accessed whilst the
heat shield is in situ.




Figure 3. Heat Shield Layout



Direct air kit fitting guide

Optional accessory instructions

EN13240:2011 +A2:2004


BK 737 Rev 02

ISSUE DATE : 14/01/2020



Direct air kit fitting guide

1. Contents Of Kit :



2. Warnings



IMPORTANT—Please ensure the appliance is cold and unlit before commencing fitting this accessory kit.

Please refer to the main instruction booklet relevant to your stove, for guidance and operation of the appliance.

Arada Ltd will not be responsible for any consequential or incidental loss or injury however caused.

Please note, this accessory kit can only be fitted **prior** to the appliance (stove) being installed and connected to the flue system, within the property.

When handling the components of the kit, it is recommended to wear suitable gloves to prevent hand injuries.


Direct air kit fitting guide

3. Fitting Instructions

Step 1 : Working at the rear of the appliance, locate the base mount rails, as shown below.

Step 2 : Take the direct air plate and slide the open end into the stove, resting the base of the plate onto the base mount rails. Slide the plate forward until the rear fold makes contact with the rear of the appliance.

Step 3 : Secure in place using the M5 screws and M5 washers supplied, as shown below.



Direct air kit fitting guide

Notes :

Arada Ltd,
The Fireworks, Weycroft Avenue,
Axminster, Devon,
United Kingdom,
EX13 5HU